

*“GenStone dramatically changed the look of our home. We’ve received lots of compliments from our neighbors. I’m sure it increased the value of our house, the whole project took about a week.”*

## TOM • KENAI STACKED STONE



### COST TO INSTALL

Fasteners • Adhesive • Caulking  
\$2 - \$5

### STEP 1

Ready to Install Out of the Box

### STEP 2

Measure, Cut, Level and Attach

### STEP 3

Enjoy!

### INSTALLATION TIME

(approx 100 SQFT)  
90 -120 Minutes

### SKILL LEVEL

Basic Carpentry Skills

### WATERPROOF

Yes

### INSULATION VALUE

3.6 Per Inch

### WEIGHT

Approx 1 - 1.5 LBS per SQFT

### SUBSTRATE REQUIREMENTS

No Prep Work. Flat Solid Substrate with Vapor Barrier (if required)

### REQUIRED TOOLS

Safety Glasses, Saw, Tape Measure, Level, Caulking Gun, Utility Knife, Screw Gun

## STONE WITH CLIPS

### COST TO INSTALL

Starter Strip • Fasteners • Adhesive • Caulking  
\$10 - \$13

### STEP 1

Install Starter Strips on Walls, Around Doors and Windows, Material Transitions or Terminations

### STEP 2

Layout Stone Pieces, Cut Pieces to Fit with Masonry Blade, Insert Screws or Nails into Each Clip on Every Stone

### STEP 3

Grind Sharp Edges, Paint Exposed Starter Strips, Start Next Row of Pieces

### INSTALLATION TIME

(approx 100 SQFT)  
6 - 8 Hours

### SKILL LEVEL

Moderate Carpentry Skills

### WATERPROOF

No

### INSULATION VALUE

None

### WEIGHT

Approx 12 LBS Per SQFT

### SUBSTRATE REQUIREMENTS

Vapor Barrier, Starter Strips

### REQUIRED TOOLS

Safety Glasses, Goggles and Grinding Face Shield, Hammer, Circular Saw, Hand Grinder, Chop Saw, Wet Saw with Diamond Blade, Level, Chalk Line, Tape Measure, Tin Snips, Brush, Screw Gun

## CAST OR NATURAL STONE

### COST OF INSTALLATION

Vapor Barrier • Mortar • Lathe  
\$12 - \$15

### STEP 1

Install Vapor Barrier, Fasten Lathe, Mix Mortar, Apply Scratch Coat, Wait Until Dry, Snap Chalk Lines

### STEP 2

Moisten Scratch Coat, Cut Stones to Size with Masonry Saw, Apply Mortar to Back of Stones

### STEP 3

Mix Grout, Apply Grout Between Stones, Tool and Clean Grout, Wait Until Dry

### INSTALLATION TIME

(approx 100 SQFT)  
12 - 16 Hours

### SKILL LEVEL

Mason

### WATERPROOF

No

### INSULATION VALUE

None

### WEIGHT

Approx 12 LBS Per SQFT

### SUBSTRATE REQUIREMENTS

Vapor Barrier, Mesh or Metal Lathe, Scratch Coat, Mortar Setting Bed

### REQUIRED TOOLS

Safety Glasses, Hammer or Staple Gun, Dust Mask, Wheelbarrow, Hoe, Hawk and Trowel, Wisk Broom, Masonary Circular or Table Saw with Diamond Blade, Wide Mouth Nippers or Hatchet, Grout Bag, Metal Jointing Tool, Level, Tape Measure

# NO MORTAR NO MESS